

GIANT

Saddle Setup

Installation

1. For reach and height, measure from the point where your original saddle is 80mm wide.
2. Prior to installing your new CADEX saddle, confirm that your seatpost clamp is compatible with 7mm or 9mm rails.
3. Begin installation by placing the saddle rails between the rail clamps and gently tighten to hold saddle in place.
4. Level the saddle using the middle 1/3 section as illustrated below. In general, your saddle should be at a neutral angle, so that you sit on the middle section of the saddle, and don't slide forward on the nose or back off the rear.



5. Tighten rail clamps to the recommended torque specification of the seatpost.
NOTE: It's normal to see some disfiguration of the clear coat on carbon saddle rails after tightening to specified torque.

Maintenance

- Use water or a diluted alcohol solution and a soft clean towel to clean the surface of the saddle.
- Check torque on the rail clamps regularly.