


CONTROL BLAST 16g/25g


S/N:
610000186
610000187
610000188




Presta valve only




Remove the plastic spacer.




Thread in CO2 cartridge.



Loosen valve core before
inflation.



To start and control the CO2 flow,
turn the valve halfway to release
CO2.



Stop the CO2 flow by tightening
the CO2 cartridge into Control
Blast.